

Soundsphere

Division of Sonic Systems Inc
10 Research Dr Stratford CT 06615

For technical support call 203-386-9200

Soundsphere Model Q12A Installation Instructions

General

Maximum amplifier power 250 watts RMS
Nominal Impedance 8 ohms

Wiring

Amplifier connection is via flying leads
Connect the positive (+) amplifier lead to the **RED** input wire
Connect the negative (-) amplifier lead to the **BLACK** wire
Secure connections using wire nuts, etc.

Mounting

Hanging Kit

Hang using one of the following methods:

- Properly secured wire rope with a minimum breaking strength of 400 lbs. (for a 10:1 safety factor)
- Beam clamp with proper load rating

It is recommended to use a secondary wire rope support around one of the Q12A legs for safety.

Do not use rope for mounting. The use of chain is not recommended unless rated for overhead suspension of loads greater than or equal to 400 lbs (for a 10:1 safety factor).

Surface Mount Bracket

Secure the bracket to the hard surface using proper hardware. Secure the Q12A to the bracket using the washers and nylon locknuts provided. It is recommended to use a secondary wire rope support around one of the Q12A legs and through an unused bracket hole for safety.

Warranty

Soundsphere loudspeakers carry a 5 year limited warranty. See warranty sheet for details and limitations.

Replacement Parts

12" 250 Watt coaxial loudspeaker driver with crossover

Order Model Number CX-12

Always check local requirements for overhead suspension of loudspeakers